

## **Twinn Rexx Assembly Manual Figures**






Figure 1a.



Figure 1b.



Figure 1c.



Figure 1d.



Figure 1e.



Figure 1f.




Figure 1g.




Figure 1h.



Figure 2a.



Figure 2b.



Figure 2c.




Figure 2d.





Figure 2e. Figure 2f.






Figure 2g. Figure 2h.





Figure 2i. Figure 2j.




Figure 3a.




Figure 3b.




Figure 4a.




Figure 4b.




Figure 4c.




Figure 4d.








Figure 5b.




Figure 5c.




Figure 5d.



Figure 5e.



Figure 5f.




Figure 7a.






Figure 8a.



Figure 8b.



Figure 8c.




Figure 8d.



Figure 8e.




Figure 8f.




Figure 10a.



Figure 10b.



Figure 11a.



Figure 11b.




Figure 12a.



Figure 12b



Figure 12c.




Figure 12d



Figure 12e



Figure 12f